



add wood step on northside & southside of landing step x 2

relay 50% - 60% existing pavers - not in carpentry scope

Length - 74 ft
 Height - 6.5 ft
 Materials - treated
 board spacing - Tight

- Scope :
- remove fence and handrail on landing
 - excavate for post holes
 - supply install fence
 - remediate pavers approx 50 - 60% (not in carpentry scope)
 - 2x4 handrail
 - install 2 steps
 - clean and haul debris

bottom edge of boards 2" above pavers to maximize fence height (not exactly as represented in this sketch)